


DISHWASHING - GET THE BEST RESULTS



<p>DISHWASH MULTI For use in soft water</p>  <p>A choice of low foam detergents with an excellent cleaning action to leave crockery & utensils clean & bright. They have been formulated to prevent limescale formation & re-deposition of soil & are suitable for use in all types of dishwashing machines.</p>	<p>DISHWASH For use in soft to medium hard water</p> 	<p>DISHWASH EXTRA For use in soft to very hard water</p> 	<p>DISHWASH CHLOR For use in soft water</p>  <p>The blend of alkali & sodium hypochlorite will remove heavy soiling & tannin.</p>	<p>TRAYWASH For use in all water conditions</p>  <p>Safe for cleaning aluminium trays, utensils, stainless steel & glazed crockery.</p>	<p>RINSE AID For use in all water conditions</p>  <p>Eliminates water spotting & provides smear free results.</p>	<p>DESCALE Concentrated acid formulation</p>  <p>Removes limescale & heavy soiling. Safe on stainless steel.</p>	<p>PSP Pre soak powder DESTAIN Tannin remover</p>  <p>Removes stains & built up protein deposits</p>	<p>EST-EEM Cleaner sanitiser Passes EN1276</p>  <p>To sanitise interior, exterior, edges, seals & surrounds of dishwash machines.</p>
--	---	---	---	---	---	--	---	---